Magic Mouse

Quick Start

Your wireless Apple Magic Mouse comes with two AA batteries installed and uses Bluetooth® technology to connect to your Mac.

Read these instructions to set up your mouse with a new Mac, replace your USB mouse, pair your mouse with a different Mac, and replace the batteries.

Updating Your Software

To use your Apple Magic Mouse and its full range of features, update your Mac to Mac OS X version 10.5.8 or later and install the Wireless Mouse Software Update 1.0; or update to Mac OS X version 10.6.2 or later.

To update to the latest version of Mac OS X, choose Apple () > Software Update from the menu bar, and follow the onscreen instructions.

When installation is complete and you restart your Mac, use Software Update again to make sure all of the available updates are installed.

About the Indicator Light

The indicator light displays the status of your Apple Magic Mouse and the batteries.

- When you first turn your mouse on, the indicator light glows steadily for 5 seconds, indicating the batteries are good.
- If your mouse isn't paired with a Mac, the light blinks, indicating your mouse is in discovery mode and ready to pair (pairing means your mouse and Mac are wirelessly connected to each other and ready to communicate).
- If you don't pair your mouse with your Mac within 3 minutes, the light and mouse turn off to preserve battery life. Slide the On/off switch on the bottom of your mouse to turn it on again, allowing you to pair it with your Mac.
- When your mouse is on and paired, with the batteries charged, the light glows steadily.



Pairing with a New Mac

Follow the instructions in the user guide that came with your Mac to set it up. Skip the instructions for connecting a USB mouse.

The first time you start up your Mac, Setup Assistant guides you in pairing your Apple Magic Mouse with your Mac.

To pair your mouse with a new Mac:

1. Slide the On/off switch on the bottom of your mouse to turn it on (see page 4).
2. Turn on your Mac and follow the onscreen instructions in Setup Assistant.
3. Once your mouse is paired with your Mac, use Software Update again to make sure you have the latest software installed (see page 3).

Replacing a USB Mouse

Use your existing USB mouse to pair your Apple Magic Mouse with your Mac.

You can also use this information to pair your mouse with a portable Mac.

To replace a USB mouse:

1. Slide the On/off switch on the bottom of your Apple Magic Mouse to turn it on (see page 4).

2 Choose Apple () > System Preferences, and then click Mouse.

3 Click "Set Up Bluetooth Mouse …" in the lower-right corner.

4 Select your mouse, and then follow the onscreen instructions to pair it with your Mac.

5 Disconnect the USB mouse from the USB port.

Pairing with A Different Mac

After you pair your Apple Magic Mouse with a Mac, you can pair again with a different Mac. To do this, remove the existing pairing, and then pair the mouse again.

To pair with a different Mac:

1 Choose Apple () > System Preferences, and then click Bluetooth.

2 Select your mouse in the Bluetooth preferences pane.

3 Click the Delete (–) button in the lower left corner.

To pair your mouse again, see "Replacing a USB Mouse" on page 5.

Using Your Apple Magic Mouse

Your Apple Magic Mouse has a seamless Multi-Touch surface you can use to right-click, left-click, scroll, and swipe. To set up Multi-Touch gestures and customize the way your mouse works, choose Apple () > System Preferences, and then click Mouse.

Replacing the Batteries

Your Apple Magic Mouse comes with two AA batteries installed. You can use alkaline, lithium, or rechargeable AA batteries in your mouse.

Dispose of batteries according to your local environmental laws and guidelines.

To replace the batteries:

1. Slide the latch down and remove the battery cover.
2. Insert the batteries with the positive (+) end facing up, as shown in the illustration.
3. Replace the battery cover.



You may have to click your Apple Magic Mouse once to reconnect it with your Mac.

> ***WARNING:*** Replace both batteries at the same time. Don't mix old batteries with new batteries or mix battery types (for example, alkaline and lithium batteries). Don't open or puncture the batteries, install them backwards, or expose them to fire, high temperatures, or water. Don't charge the nonrechargeable AA batteries that came with your mouse. Keep batteries out of the reach of children.

Battery Level Indicator
To check the battery level, choose Apple () > System Preferences, and then click Mouse. The battery level indicator is in the lower-left corner.

Note: When you aren't using you mouse, it goes to sleep to conserve battery power. If you won't be using your mouse for an extended period, turn it off.

Cleaning

To clean the outside of your mouse, use a lint-free cloth that's been lightly moistened with water. Don't get moisture in any openings or use aerosol sprays, solvents, or abrasives.

Ergonomics

For information about ergonomics, health, and safety, visit the ergonomics website at www.apple.com/about/ergonomics.

More Information

For more information about using your mouse, open Mac Help and search for "mouse."

For support and troubleshooting information, user discussion boards, and the latest Apple software downloads, go to:
www.apple.com/support

クイックスタート

お求めのワイヤレス Apple Magic Mouse は、2 本の単三電池があらかじめ入っており、Bluetooth® テクノロジーを使用して Mac に接続します。

新しい Mac でマウスを設定したり、USB マウスを交換したり、別の Mac にマウスを登録したり、電池を交換したりするときは、以下の手順をお読みください。

ソフトウェアをアップデートする

Apple Magic Mouse とそのすべての機能を使用するには、お使いの Mac を Mac OS X バージョン 10.5.8 以降にアップデートしてワイヤレス・マウス・ソフトウェア・アップデート 1.0 をインストールするか、Mac OS X バージョン 10.6.2 以降にアップデートしてください。

Mac OS X を最新バージョンにアップデートするには、メニューバーからアップル（）メニュー＞「ソフトウェア・アップデート」と選択し、画面に表示される指示に従います。

インストールが完了し、Macを再起動したら、もう一度「ソフトウェア・アップデート」を実行して、利用可能なアップデートがすべてインストールされているかどうかを確認します。

インジケータランプについて

インジケータランプには、Apple Magic Mouse と電池の状態が示されます。

- マウスの電源をはじめて入れると、インジケータランプが 5 秒間点灯します。これは電池の状態が良好であることを示します。
- マウスが Mac に登録されていない場合は、ランプが点滅します。これは、マウスが検出モードにあり、登録する準備ができていることを示します（登録とは、マウスと Mac がワイヤレスで接続されて相互に通信できるようにする作業を言います）。
- 3 分以内にマウスを Mac に登録しないと、ランプが消え、電池を節約するためにマウスの電源が切れます。マウスの底面のオン／オフスイッチをスライドして電源を入れ直すと、Mac に登録できる状態になります。
- マウスの電源が入っていて登録済みで、電池が充電されているときは、ランプが点灯します。



新しい Mac に登録する

お求めの Mac に付属するユーザーガイドに従って、Mac を設置してください。USB マウスを接続するための手順は省略してください。

はじめて Mac を起動すると設定アシスタントが表示されるので、画面の指示に従って Apple Magic Mouse を Mac に登録します。

マウスを新しい Mac に登録するには：

1 マウスの底面のオン／オフスイッチをスライドして電源を入れます（11 ページを参照）。

2 Mac の電源を入れ、設定アシスタントの画面に表示される指示に従います。

3 Mac にマウスが登録されたら、もう一度「ソフトウェア・アップデート」を実行して、最新のソフトウェアがインストールされているかどうかを確認します（10 ページを参照）。

USB マウスを交換する

すでにお持ちの USB マウスを使用して、Apple Magic Mouse を Mac に登録できます。

同じ手順で、マウスをノート型 Mac に登録することもできます。

USB マウスを交換するには：

1 Apple Magic Mouse の底面のオン／オフスイッチをスライドして電源を入れます（11 ページを参照）。

2 アップル（）メニュー＞「システム環境設定」と選択して、「マウス」をクリックします。

3 左下隅にある「Bluetooth マウスを設定 ...」をクリックします。

4 マウスを選択してから、画面に表示される指示に従って Mac に登録します。

5 USB マウスを USB ポートから取り外します。

別の Mac に登録する

Apple Magic Mouse を Mac に登録した後で、別の Mac に登録し直すことができます。そのためには、既存の登録を解除してから、マウスを登録し直します。

別の Mac に登録するには：

1 アップル（）メニュー＞「システム環境設定」と選択して、「Bluetooth」をクリックします。

2「Bluetooth」環境設定パネルでマウスを選択します。

3 左下隅にある削除（－）ボタンをクリックします。

マウスを登録し直すときは、12 ページの「USB マウスを交換する」を参照してください。

Apple Magic Mouse を使用する

Apple Magic Mouse のボタンのないマルチタッチサーフェスを使って、右クリック、左クリック、スクロール、スワイプすることができます。マルチタッチジェスチャを設定したりマウスの動作をカスタマイズしたりするには、アップル（）メニュー＞「システム環境設定」と選択し、「マウス」をクリックしてください。

電池を交換する

お求めの Apple Magic Mouse には、2 本の単三電池があらかじめ入っています。単三のアルカリ電池、リチウム電池、または充電式電池をマウスに使用することもできます。

電池を廃棄する際は、お住まいの地域の条例および規則に従ってください。

電池を交換するには：

1 ラッチを下にスライドして、電池カバーを取り外します。

2 図のようにプラス極（＋）側を上に向けて電池を入れます。

3 電池カバーを元に戻します。



Apple Magic Mouse を Mac に再接続するために、1 回クリックしてください。

警告： 2 本の電池を同時に交換してください。古い電池と新しい電池を組み合わせたり、異なる種類の電池（たとえばアルカリ電池とリチウム電池など）を組み合わせたりしないでください。電池を解体したり、穴を開けたり、逆向きに入れたりせず、火気、高温、水気を避けてください。お求めのマウスには単三電池が付属していますが、これらは充電式ではないので充電しないでください。電池は子供の手の届かないところに保管してください。

電池の残量表示

電池の残量を確認するには、アップル（）メニュー>「システム環境設定」と選択して、「マウス」をクリックします。左下隅に電池の残量が表示されます。

参考： マウスを使っていないときは、電池を節約するためにスリープ状態になります。マウスを長期間使わない場合は、電源を切ってください。

清掃する

マウスの外面を清掃するときは、水で軽く湿らせた、けば立っていない布を使用してください。開口部に水が入り込まないように注意してください。スプレー式の液体クリーナー、溶剤、研磨剤などは使わないでください。

作業環境が身体に与える影響について

本製品を使用する環境の安全性と身体に与える影響については、作業環境に関する Web サイトを参照してください：www.apple.com/jp/about/ergonomics

さらに詳しく知りたいときは

マウスのさらに詳しい使いかたについては、「Mac ヘルプ」で「マウス」を検索してください。

サポート情報やトラブルの解決方法、ユーザ同士の情報交換、最新のアップル製ソフトウェアのダウンロードなどについては、www.apple.com/jp/support を参照してください。

Regulatory Compliance Information

Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See instructions if interference to radio or television reception is suspected.

L'utilisation de ce dispositif est autorisée seulement aux conditions suivantes: (1) il ne doit pas produire de brouillage et (2) l'utilisateur du dispositif doit étre prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

Radio and Television Interference

This computer equipment generates, uses, and can radiate radio-frequency energy. If it is not installed and used properly—that is, in strict accordance with Apple's instructions—it may cause interference with radio and television reception.

This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in Part 15 of FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

You can determine whether your computer system is causing interference by turning it off. If the interference stops, it was probably caused by the computer or one of the peripheral devices.

If your computer system does cause interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.

- Move the computer to one side or the other of the television or radio.
- Move the computer farther away from the television or radio.
- Plug the computer into an outlet that is on a different circuit from the television or radio. (That is, make certain the computer and the television or radio are on circuits controlled by different circuit breakers or fuses.)

If necessary, consult an Apple Authorized Service Provider or Apple. See the service and support information that came with your Apple product. Or, consult an experienced radio/television technician for additional suggestions.

Important: Changes or modifications to this product not authorized by Apple Inc. could void the EMC compliance and negate your authority to operate the product.

This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables (including Ethernet network cables) between system components to reduce the possibility of causing interference to radios, television sets, and other electronic devices. Turn the television or radio antenna until the interference stops.

Responsible party (contact for FCC matters only):
Apple Inc. Corporate Compliance
1 Infinite Loop, MS 26-A
Cupertino, CA 95014

Industry Canada Statements

Complies with the Canadian ICES-003 Class B specifications. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. This device complies with RSS 210 of Industry Canada. This Class B device meets all requirements of the Canadian interference-causing equipment regulations. Cet appareil numérique de la Class B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Europe— EU Declaration of Conformity

For more information, see www.apple.com/euro/compliance.

Apple Magic Mouse Class 1 Laser Information

The Apple Magic Mouse is a Class 1 laser product in accordance with IEC 60825-1 A1 A2 and 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated July 26, 2001.

Caution: Modification of this device may result in hazardous radiation exposure. For your safety, have this equipment serviced only by an Apple Authorized Service Provider.

CLASS 1 LASER PRODUCT
LASER KLASSE 1
APPAREIL A RAYONNEMENT
LASER DE CLASSE 1

A Class 1 laser is safe under reasonably foreseeable conditions per the requirements in IEC 60825-1 AND 21 CFR 1040. However, it is recommended that you do not direct the laser beam at anyone's eyes.

Apple and the Environment

Apple Inc. recognizes its responsibility to minimize the environmental impacts of its operations and products. More information is available on the web at www.apple.com/environment.

Korea KCC Statement

명 칭/모 델 명: Apple Magic Mouse / A1296
인 증 번 호: APL-A1296
인 증 자 상 호: 애플컴퓨터코리아(주)
제 조 년 월: 별도표기
제조자/제조국: Apple Inc. / 중국

Singapore Wireless Certification

Complies with
IDA Standards
DB00063

Korea Statements

”당해 무선설비는 운용 중 전파혼신 가능성이 있음”
”이 기기는 인명안전과 관련된 서비스에 사용할 수 없습니다

B급 기기(가정용 방송통신기기)

이 기기는 가정용(B급)으로 전자파적합등록을 한 기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

Taiwan Wireless Statement

無線設備的警告聲明

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

VCCI Class B Statement

情報処理装置等電波障害自主規制について

この装置は、情報処理装置等電波障害自主規制協議会 (VCCI) の基準に基づくクラス B 情報技術装置です。この装置は家庭環境で使用されることを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取扱をしてください。

中国

有毒或有害物质	零部件		
	电路板	附件	电池
铅 (Pb)	X	O	X
汞 (Hg)	O	O	O
镉 (Cd)	O	O	O
六价铬 (Cr, VI)	O	O	O
多溴联苯 (PBB)	O	O	O
多溴二苯醚 (PBDE)	O	O	O

O: 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 规定的限量要求以下。

X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 规定的限量要求。

根据中国电子行业标准 SJ/T11364-2006 和相关的中国政府法规，本产品及其某些内部或外部组件上可能带有环保使用期限标识。取决于组件和组件制造商，产品及其组件上的使用期限标识可能有所不同。组件上的使用 期限标识 优先于产品 上任何与 之相冲突 的或不同的环保使用期限标识。

Disposal and Recycling Information

When this product reaches its end of life, please dispose of it according to your local environmental laws and guidelines.

For information about Apple's recycling programs, visit: www.apple.com/environment/recycling

Battery Disposal Information

Dispose of batteries according to your local environmental laws and guidelines.

Deutschland: Das Gerät enthält Batterien. Diese gehören nicht in den Hausmüll. Sie können verbrauchte Batterien beim Handel oder bei den Kommunen unentgeltlich abgeben. Um Kurzschlüsse zu vermeiden, kleben Sie die Pole der Batterien vorsorglich mit einem Klebestreifen ab.

Nederlands: Gebruikte batterijen kunnen worden ingeleverd bij de chemokar of in een speciale batterijcontainer voor klein chemisch afval (kca) worden gedeponeerd.

Taiwan:

廢電池請回收

European Union—Disposal Information



The symbol above means that according to local laws and regulations your product should be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. Some collection points accept products for free.The separate collection and recycling of your product at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

J034-5283-A
Printed in XXXX